

9/12/2024 (rev 0)

Topic: Rack Thermocouple Calibration

## Grease Thief Analyzer Heating Rack Thermocouple Calibration

### REQUIRED TOOLS AND INSTRUMENTS

1. Grease Thief Analyzer
2. Calibrated digital thermocouple
3. Computer and cabling for connection
4. Extendable mirror from toolbox (optional)

### PROCEDURE

#### 1. Calibration of the Rack Thermocouple in GTA

- a. Obtain a calibrated digital thermometer with a thermocouple attachment.
- b. Lay the thermometer in the heating rack, next to the instrument sensor. The tips should be as close to each other as possible.
- c. From the main screen on the GTA control panel go to Temperature Control.
- d. Turn the preheating rack on and set to 21°C. The firmware keeps the rack at 5°C above the set point, so you will be starting at 26°C.
- e. Watch the instrument reading on the Temperature Control -> Temp Cal screen.
- f. Set the timer for 5 min and wait for the reading to stabilize. The tenths digit on the display may bounce slightly +/- 0.2°C, but it should be relatively consistent and it should be near the expected value.
- g. If the temperature isn't stable even after an extended wait period, check the PID settings found in the manual or the sensor may be damaged.
- h. After a 5 min wait, record the stable value seen on the instrument display and the value seen on the thermometer.
- i. Repeat step 3-5 for 2°C intervals up to 40°C.
- j. Recorded values are to be entered into the calibration template.
- k. The thermometer will be your x values and the sensor display will be your y values in a coordinate system.
- l. Plot the points using the template thermocouple calibration template
  - i. Thermometer values go in Column A
  - ii. Sensor values go in Column B

- m. Review the best fit curve of the plotted data. Your results should follow a linear relationship with  $R^2$  value  $>0.90$ . If they do not, consider rerunning the trial, or removing outliers until the plot is linear. If a linear response cannot be achieved, consult MRG Labs.
- n. Put the  $m$  and  $b$  values from the  $y=mx+b$  fit into the labeled cells on the template.
- o. Put the current gain and offset into the labeled cells in the template. The values can be obtained from the GTA instrument by going to the Temperature Control->Temp Cal screen.
- p. **Cal Check:** If the best fit trend line for your trial falls within acceptable tolerances  $0.85 < m < 1.15$  and  $-5 < b < 5$ . The template will display 'Passed' and the calibration is complete. Resave the file in the calibration folder with the proper format and the date.
- q. If the calibration does not pass, take the "new" calculated gain and offset values from row 4 and enter them into the instrument.
- r. The new values can be input into the **Temp Cal** screen. Main-> Temperature Control->Temp Cal.

## 2. Calculations

- a. To calculate the new Gain and offset values take the equation from your best fit line:  $y=mx+b$  and the current values for the Gain and offset in the instrument Temp Cal screen:  $\text{Gain}_{\text{Current}}$ ,  $\text{Offset}_{\text{current}}$  and put them into the equation below. This calculation is done automatically by the calibration template.
- b. New Gain=  $(\text{Gain}_{\text{Current}}) / (m)$
- c. New Offset=  $-b/m + \text{Offset}_{\text{Current}}$